TaichuPix1 Measurement


Tianya Wu CEPC Meeting twu@ifae.es 28-12-2020








Readout priority order for digital periphery



- The whole matrix could divide into 3 parallel groups, periphery would scan the group one by one.
- Inside each group, the priority order is from right to left, col191, col127 and col63 are the top priority. And GROUP2 is a mixture group.
- Timestamp is added at the end of column, so when many injection hits arrive at the same time, only higher priority position could be recorded.
- FE-I3 part data density in GROUP2 will be higher than GROUP1.



LVDS DATA Results



- I selected the data from a 120MB files.
- Process all of the data, I will find a lot of errors inside.
- I picked the data with timestamp range [47,128]





Fig4 More Triggerless data integration




Principle of Analog Front End

Here are schematics of Analog front end with the design parameters and the waveform result.











Turn on one column to do analog calibration






Fit curve of test result



Apulse injection for 100 times

TaiChuPix1 Hits


Eneraies



- I select the COL52 /ROW63 to calculate the probability due to its top priority.
- Scan the dV=Vhigh-Vlow from 0.2V to 0.7V with step of 0.05V
- Sometimes the LVDS output count rate would be over 100. It might be error from noise?
- The trend of the fit curve meets what I expect but not always be 100% when dV is over 0.6V, it exists some small jitter.
- The threshold of dV is around 450mV (Qin~511e-)



Turn on 4 Pixels for analog calibration





Thanks for your attention.

10