



中國科學院為維物服研究所 Institute of High Energy Physics Chinese Academy of Sciences

Status of readout electronic design in MOST1

Na WANG, Ke WANG, Zhenan LIU, Jia TAO

On behalf of the Trigger Group (IHEP)

Mini-workshop for CEPC MOST silicon project,23 November,2017,Beijing

Outline

- Introduction on readout electronics in MOST1
- R&D activities
 - -Data acquisition with oscilloscope
 - -Data acquisition with ADC
- Summary and future plan

R&D activities

- Two versions of daughter-board designed and fabricated
- Two versions of mother-board (1st designed and fabricated ,2nd in process)
- Single analog readout channel verified with oscilloscope and ADC sampling
- FPGA Firmware Design
- Digital controlling (IP is under packaged)


Introduction on the readout electronics

- Measurements of the prototype pixel devices
- To validate their usefulness for future application
- 1st CPS Prototype Characterization
 - ✓ Verification of basic electrical parameters estimation of the collected charge
 Noise, signal dynamic range response of the device to the light pulses
 - ✓ Tests using ⁵⁵Fe radioactive source


Daughter Board → Mother Board → FPGA board

Mother Board ADC sampling.

16-bit ADC resolution



Two versions of daughter and mother board




Daughter board:1st to 2nd fabricated and tested



Daughter
→ Mother board design.

Mother board: 1st, fabricated and tested 2nd under designed



Interface to mother board:

- power supplies ,read-out clock
- address and other controlling signal
- read-back synchronization signal
- 16 pairs of differential analog and digital output


Interface to NI chassis:

- 16 analog output
- clocks and synchronization signals

Signal dynamic range

- Single input ,differential output
- Low noise amplification of the signal (multiplied by 3 ~10)
- Dynamic range(e.g. 50mV Vpp→500mV Vpp)







Data acquisition with oscilloscope

Data acquisition with oscilloscope







- Sensitive to visible light data acquisition :
- Oscilloscope data acquisition and storage 2 frame/pic, 2M clock
- 5000 point data


Data processing:

- Remove oscilloscope background noise
- Pixel output noise:
 - 1.6mV

simulation pixel charge gain 20uV/e,

equivalent noise charge, ENC-- 80e –

 48 rows noise and background distribution Data acquisition with oscilloscope




• 55Fe Radioactive Source:

5.9 keV X-ray source Observed signals :

2M clock,2 frames/pic

 Multi event trigger mode selection,10G raw data for processing




Data acquisition with ADC sampling

Digital controlling--FPGA firmware design

Digital controlling Block diagram based on Xilinx KC705

- CEPC CPS control:
 - -clock selection:2M,4M
 - -address set :A0:A7
- ADC control
 - clock
 - -enable
- ADC data read out
 - -readout clock




- Data pre-processing
 - --Serial parallel conversion storage in local memory (in progress)

Digital controlling—ADC verification


ADC Characterization verifying

- --ILA captured data 1.5VDC SDO is the same as the oscilloscope's waveform
- --ILA captured data 250KHz 4Vpp 2VDC offset Sine wave (signed decimal)



Data acquisition ADC sampling

VIVADO ILA captured data (displayed in analog style)



Summary and future plan

Accomplished:

 Read-out system for MOST-1, single channel data apquisition and transmission

basic characteristic-signal dynamic range

-noise performance

-the digital controlling for chip and FPGA

--single channel data CDS (48rows in one selected column)

Future plan:

 Read-out system:16 channel*16bit *clock data convention and transmission, storage in local memory


CEPC CPS1 prototype chip testing plan


- 1.Tests under Infrared Laser -- Time of Charge Collection
 - (time properties of charge collection, undepleted epitaxial layer)
 - -- spatial resolution and detection efficiency
- 2. Tests with Soft X-rays (55 Fe source) -- Temporal noise and spatial non-uniformities in pixel responses

 - -- Charge Collection Efficiency and Cluster Signal Distribution
 - -- Soft X-ray spectroscopy
 - -- Charge Distribution

3. Radiation testing:

TID anti-radiation testing Single event effect Displacement effect testing (Neutron irradiation)





Thank you!