

CEPC ECAL

Jianbei Liu

on behalf of the CEPC calorimeter working group

State Key Laboratory of Particle Detection and Electronics

University of Science and Technology of China

CEPC CDR International Review

Physics & Detector

IHEP, Beijing


September 14, 2018

ECAL CDR Team

- IHEP, China
 - Zhigang Wang, Mingyi Dong, Hang Zhao, Manqi Ruan, Bing Zhao, Tao Hu
- USTC, China
 - Yunlong Zhang, Yazhou Niu, Shensen Zhao, Zhongtao Shen, Changqing Feng, Shubin Liu, Jianbei Liu
- LLR, France
 - Vincent Boudry, Jean-Claude Brient

Jet measurement at CEPC

- Separation of W/Z bosons in their hadronic decays translates into a jet energy resolution requirement of $\sim 30\% / \sqrt{E}$ ($E < 100\text{GeV}$).




$WW \rightarrow 4j$ and $ZZ \rightarrow 4j$

Particle Flow Algorithm

- Particle Flow Algorithm (PFA) is a very promising approach to achieving the unprecedented jet energy resolution of 3%-4%.
 - All particles are individually reconstructed.
 - Energy/momentum of each particle in a jet is determined by making use of the optimal sub-detector.
- A highly segmented and full-contained calorimeter system is required, and combined with a transparent and high-resolution tracking system.

PFA calorimeters





- Analog ECAL options are considered for CEPC.

ECAL Design Considerations

- A sampling calorimeter consisting of sensitive layers of either silicon pads or scintillator tiles interleaved with tungsten absorber layers.
 - Tungsten (W): short radiation length, small Moliere radius, large ratio of interaction length over radiation length.
 - Two detector options from the two sensitive materials:
 - Si-W, Sci-W
- Highly segmented both transversely and longitudinally for excellent particle shower separation.
- Si-W is taken as the ECAL baseline option.

Design Optimisation (I)



- Total absorber thickness \rightarrow 84 mm



Benchmarked with $H \rightarrow \gamma\gamma$: Higgs mass vs. thickness

Design Optimisation (II)

- Number of sampling layers \rightarrow 30



Single photon energy resolution vs. Number of layers and Silicon thickness
Constant absorber layer thickness vs. Varying thickness


Baseline: 30 layers of 0.5mm silicon, 2.1mm W for first 20 layers and 4.2mm for the last 10 layers.

Design Optimisation (III)

- Cell size $\rightarrow 10 \times 10 \text{ mm}^2$

Silicon sensor size (mm)	Higgs boson mass resolution (with statistic error)
5	$3.74 \pm 0.02 \%$
10	$3.75 \pm 0.02 \%$
20	$3.93 \pm 0.02 \%$

Higgs mass in $H \rightarrow gg$ vs. cell size



Di-photon reco. efficiency

Cell size (mm)	Percentage of inseparable photons
1	0.07%
5	0.30%
10	1.70%
20	19.6%

Percentage of inseparable photons
from τ decays in $Z \rightarrow \tau\tau$ events

ECAL Baseline Design Profile


- A Si-W sandwich calorimeter
- Absorber
 - 30 layers of W plates: 20 layers of 2.1mm plates followed by 10 layers of 4.2mm plates.
 - 84 mm thick in total ($24 X_0$)
- Active medium
 - 30 layers of Si plates, 0.5 mm thick each, divided into square cells of $10 \times 10 \text{ mm}^2$ each.

Sensor

- Silicon PIN diodes with high resistivity
 - Stable operation
 - Uniform response
 - Flexible geometry
 - High signal to noise ratio
 - Costly

Layout and Structure

- One cylindrical barrel + two disk-like endcaps
- 2.028 m in radius, and 5.270 m long.
- 8 barrel sections: 1 section \rightarrow 8 staves, 1 stave \rightarrow 5 modules, 1 module \rightarrow 5 columns
- Each endcap \rightarrow 4 quadrants, 1 quadrant \rightarrow 9 columns
- Column: slabs integrated into supporting structures
- Best possible hermeticity and minimum crack regions



Electronics Parameters

- Numbers of channels
 - 17.3 M for barrel, 7.43 M for endcaps
- Dynamic range
 - 9.6 fC (MIP) - 96pC (EM shower) → 10000
- Timing
 - ~1ns for 5MIPs with SKIROC. Can be enhanced with dedicated electronics.
- Power consumption
 - 5 mW/ch from SKIROC in continuous mode, desirable to be further reduced.
- Occupancy
 - Very low, room for ultra-low power electronics design



Power consumption and cooling

- Total power consumption
 - 124 kW (SKIROC) + 22 kW (DIF) ~ 146 kW
- Active cooling is the baseline cooling scheme, and a two-phase, low mass CO₂ cooling system is a promising technology option.
- Passive cooling is also considered, but requires a reduced density of channels.
 - May work for ECAL with a cell-size of 20mm*20mm

An alternative ECAL: Sci-W



- Advent of compact photo sensors made this option possible. Big advantage in cost due to use of scintillator.
- Layout and structure quite similar to Si-W
- The primary difference is in the thickness of active layers
 - 2 mm thick scintillator
- Scintillator read out with SiPM
- Explore strip configuration to get a higher effective granularity
 - Have adjacent scintillator strip layers placed perpendicular to each other

Layout of a Sci-W module



- More studies required to demonstrate the effectiveness of the strip configuration



SiPM dynamic range



- A dynamic range of up to ~ 800 MIPs is required for $H \rightarrow \gamma\gamma$ measurement. This corresponds to ~ 10000 PEs assuming 15 PEs for a MIP.
- High-pixel SiPM (small pitch, e.g. $10 \mu\text{m}$, or large-area) is needed.

Scintillator Sensitive Unit


- Bottom-center: the best coupling of SiPM to scintillator strip.
 - Good uniformity
 - Possible to employ large-area SiPMs



ESR is a good reflector film

SiPM Readout and Calibration

- SPIROC chip can be a starting point for SiPM readout of CEPC ECAL.
 - Large dynamic range and good charge resolution
 - Sub-ns timing resolution
 - Modifications needed to accommodate the CEPC continuous mode
- A SiPM monitoring and calibration system consisting of pulse generators, chip LEDs, and notched fibers is considered.



Summary

- Baseline PFA ECAL for CEPC
 - Si-W, 30 sampling layers
 - Absorber layers
 - 84 mm thick W ($24 X_0$), 20 layers of 2.1mm W plates + 10 layers of 4.2mm W plates
 - Active layers
 - 0.5 mm thick Si plates divided into square $10 \times 10 \text{ mm}^2$ cells
- Alternative option
 - Sci-W
 - 2mm thick scintillator read out with SiPM